### **Rx COIL FOR HIGH FREQUENCY WIRELESS POWER TRANSFER**

### **Product Name**

Wireless Charging Coil - High Frequency Receive

Molex PN	Part Description			
1461798021	Wireless Charging Coil - High Frequency Receive			

<b>REVISION:</b>	ECR/ECN INFORMATION:	TITLE: <u>Rx COIL FOR HIGH FREQUENCY WIRELESS</u>			SHEET No.
В	<u>EC No:</u> 111410				<b>1</b> of <b>6</b>
D	<u>DATE:</u> 2016/12/28				
DOCUMENT NUMBER:		CREATED / REVISED BY:	CHECKED BY:	APPROVED BY:	
AS	-1461798021	Benson Liu 2016/12/28	Ryan Liu 2016/12/28	Welson Tan 2016/12/	

a molex partner

## **High Frequency Low Power Rx**

### **Rx COIL FOR HIGH FREQUENCY WIRELESS POWER TRANSFER**

#### FEATURES

- Industry's highest FPCB Q Factor
- Wearable and small form factor design
- Industry leading thinness of 0.685mm MAX (w/shield)
- Enables high efficiency solutions
- Flex construction: Increased durability Repeatable performance Integration with other electronics
- Custom design available

Molex Part Number

1461798021

Electrical Parameters at 25°C					Mechanical Parameters (mm)		
Inductance +/-2%, @ 6.78 MHz (uH)	DCR +/- 2% (mOhm)	ESR +/- 2% (mOhm)	Quality factor		Coil Thickness	Assembly Thickness (w/shield)	Material
4.0	235	1450	115		0.24	0.685 MAX	Flex



a **molex** partner

### **High Frequency Low Power Rx**

#### **GENERAL DESCRIPTION:**

This specification describes a FPCB receiver coil for wireless power transfer at frequencies 6.78 MHz. The information in this document is for reference and benchmark purposes only. The user is responsible for validating coil performance based on users own testing environment.

#### **PRODUCT DESCRIPTION:**

This high efficiency coil is designed for high performance wearable or any other device / accessory requiring up to 2.5W power out. Standard FPCB construction enables integration with other electronics, high durability, and consistent performance.

#### **DEFINITIONS:**

**Equivalent Series Resistance** (ESR): resistance measured at or around the operating frequency. ESR accurately characterizes any losses such as skin effect or proximity effect and any additional effects that may occur in the presence of material such as shielding, metal backing, or the housing. Comparison of coil assembly and in situation ESR measurements can accurately determine sources of loss. This metric should be given serious consideration during product selection to ensure full characterization of system electrical parameters.

**Direct Current Resistance** (DCR): resistance measured at DC or measured at very low frequencies (60 Hz - 100 Hz) and is often considered an incomplete measurement in wireless charging environments because it does not take into account actual causes of resistance during operation. NuCurrent recommends ESR as the most relevant measurement of resistance in a wireless power coil, but provides DCR values as well.

#### **PRODUCT TUNING:**

It is important to optimize the tuning circuit for every application. Improper tuning can lead to inferior system performance even if the individual system blocks, including the coil, comprise high performance components.

The objective of the matching circuit is to resonate the inductive coil ( $Z_{COIL}$ ) and match it to  $Z_{IN}$  (See diagram below).  $Z_{IN}$  may be variable; for example when charging a battery, there is a swing in the  $Z_{LOAD}$  value which may translate to a swing in  $Z_{IN}$ . Instead of optimizing for the full swing in  $Z_{IN}$ , a relatively straightforward approach to keep losses low may be to match for maximum efficiency when  $Z_{IN}$  is at full load (peak power draw).

A generic tuning/matching network (C1, C2, C3) is provided below as a typical system for wireless charging using magnetic resonance coupling. The topology is a shunt-series-differential-capacitor network. Depending on the application, choice of ICs, effective self-Inductance of the coil ( $L_{EFF}$ ), and coupling with the transmitter, a derivative topology (e.g. single-ended series, differential series, etc.) may also be implemented.



With regards to the capacitor-network, the choice of topology is dependent on the desired  $V_{\text{RECTIFIER}}$  and the receiver coil selection. A good rule of thumb to determine the **relative**  $V_{\text{RECTIFIER}}$  between different receive coils is to compute the product  $L_{\text{EFF}} \times A_{\text{EFF}}$ , where  $A_{\text{EFF}}$  is the effective area of the coil. Series tuning is typically preferred for high  $L_{\text{EFF}}$  coils with good coupling (to the transmitter) to induce a  $V_{\text{RECTIFIER}}$  within the desired range (typically 7V - 15V for a 4W - 7W receiver). Shunt tuning can be used with very low  $L_{\text{EFF}}$  coils with low coupling. In general, the shunt helps boost the  $V_{\text{RECTIFIER}}$ . Shunt-series tuning may be used for coils which demonstrate intermediate coupling with the transmitter; this topology also offers more flexibility towards designing for  $Z_{\text{IN}}$ .

SMT inductors (not shown) may be added in series with C2 and/or C3 to block high frequency harmonics. An EMI filter may also be utilized to prevent harmonics generated at the rectifier stage to re-enter the wireless link.

In order to account for the effect of the environment on the coil, all measurements, including  $Z_{COIL}$ , should be performed in-situ, i.e. the coil assembly placed in its intended location in the end application.

Finally, the choice of the matching topology and filtering components is a function of the desired performance, complexity and BOM.

For detailed product specific tuning information, please contact Molex at <u>www.molex.com</u> or via phone 1 800-78MOLEX (1 800 786-6539).

a molex partner

## **High Frequency Low Power Rx**

#### **PERFORMANCE:**

For custom applications, Molex and NuCurrent can optimize antenna assemblies for thickness, price or efficiency. The data below demonstrates the performance of the coil up to 2.5W.



- A Certified Class 2 transmitter used for all tests
- Tests done with receiver located in the center of Transmitter
- End-End Efficiency is defined as Rectified Power/Input Power

a molex partner

## **High Frequency Low Power Rx**

#### GENERAL REQUIREMENTS:

A. CONNECTIONS FOR TESTING

I. 34AWG copper wire recommended for through-hole soldering

#### **B. RECOMMENDED TEST SETUP**



Test Setup Block Diagram

#### **REFERENCE DOCUMENTS:**

Please see Company website for more information.

Rev B 01/03