## IRMD22141SS Demo Board

For 3-phase / 380V motor drives

#### IRMD22141SS Demo Board

International

IOR Rectifier

- Up to 1200V DC-bus capability
- Up to 50A maximum phase current
- Optional on-board phase shunt resistors
   3 x IR22141SS devices connected in 3-
- phase configuration
- On-board bootstrap supply for high-side gate drive
- Full protection of phase-to-phase, DC-bus and ground short circuit by monitoring IGBT de-saturation
- Fault feedback to ground level
- Internal minimum dead time
- Anti-shoot-through management
- Undervoltage lockout
- 3.3V digital input/output CMOS compatible

#### **Power Module**

- Standard ECONO2-6PACK IGBT module compatible
- IGBT short circuit rated up to 1200V/50A.
- Easy to mount heat-sink



IR22141SS Demo Board (Shown with optional IGBT Power Module)

## INTRODUCTION

The IRMD22141SS demo board is an evaluation board for IR22141SS gate driver. With three connected IR22141SS (see the device datasheet), IRMD22141SS is designed to drive 3-phase power modules with pin-out compatible to ECONO2-6PACK. The board can drive AC or Brushless motors using power modules with up to 50A output current. The board is a flexible solution for different applications and can be customized providing place for external components. The control signals are 3.3V CMOS compatible; three-phase shunt resistor (with sensing pins) can be placed for current loop control; power module short circuits are managed synchronizing the IGBT turn off in a local network. Board layout reduces the noise coupling between high and low voltage signals and EM emissions.



## Datasheet rev 2.1 IRMD22141SS

## Table of contents

INTRODUCTION	1
Table of contents	2
Table of figures	2
The IR22141SS	
The power module	3
Important Notice	3
BOARD CONNECTORS	4
Connection with the system controller	4
FAULT/SD logic signal	5
VCC supply pin	5
VSS ground pin (GND)	
Connecting the current sensors	5
High power signal connector	6
Connecting the power module	
Test Points	7
TEST BENCH CONNECTION	
OPERATING DESCRIPTION	
Power on sequence	
Normal operating mode	8
Fault management	
Multilevel board solution	
BOARD SOLUTIONS10	
Bootstrap circuit10	0
Gate resistances1	0
OTHER EXTRA COMPONENTS1	1
Desat circuit1	1
Clamping Diode for Vs below ground1	1
RC filter on com pin1	2
Fast diode between gate and supply pin	3
Zener diode to preserve the IGBT gate1	3
Optional output shunt resistor14	4
Resistor on $v_{cc}$	4
BILL OF MATERIAL	5
SCHEMATIC10	6
LAYOUT10	6
LAYOUT	7

### Table of figures

Figure 1: TOP image of board	4
Figure 2: LED connection	5
Figure 3: Test bench connection	
Figure 4: Power on sequence	
Figure 5: Three phase connection	9
Figure 6: Example of a desaturation detection event	9
Figure 7: Bootstrap circuit	10
Figure 8: Desat external filter	11
Figure 9: -V <sub>s</sub> clamp	12
Figure 10: COM below ground protection	12
Figure 11: Collector-Gate current protection	
Figure 12: Zener clamp for IGBT gate	

Parameters	Values	Description, condition			
Input Power DC+	0 to 1200V	DCBus voltage positive with 1200V power module			
DC-	ground	DCbus voltage negative			
Vcc	15V typ	Low voltage power supply. Follow IR22141 datasheet for supply setting			
Vss	ground	Low voltage ground			
lcc	100 mA	quiescent Vcc current			
Output Power					
llmax	50A @25C	max phase dc output current			
Control Inputs/Outputs					
40 pin connector J1 I/Os	3.3V to 15V compatible	see "Board Connectors" section on page 4			

#### The IR22141SS

The IR22141SS is a half bridge gate driver suited for power switching applications. The high side driver can float up to 1200V. The IR22141SS have a high gate driving capability (2A source and 3A sink) with a low quiescent current. The device is designed to manage all the half-bridge faults by turning off smoothly the desaturated transistor through the dedicated soft shut down pin preventing over-voltages and reducing EM emissions. In a multi-phase system the drivers communicate using a dedicated local network (SY\_FLT and FAULT/SD signals) to properly manage phase-to-phase short circuits. The system controller may force shutdown or read device fault state through the 3.3 V compatible CMOS I/O pin (FAULT/SD). To improve the signal immunity from DC-bus noise, the control and power ground use dedicated pins enabling low-side emitter current sensing as well. Undervoltage conditions in floating and low voltage circuits are managed independently.

For further technical information see the IR2214/IR22141 datasheet at http://www.irf.com.



ECONO2 6PACK

#### The power module

IRMD22141SS demo board is ECONO2 compatible with SixPack<sup>™</sup> standard pin out.

#### **Important Notice**

IRMD22141SS demo board is supplied with a Bill Of Material suitable for a 1200V/50A@100C power module. The BOM presented on page 15 provides a suggestion for the above

mentioned power module.

It is strongly recommended to customize the demo board to fit the application requirements for the power module that has been chosen.

Suggestions on passive sizing are also present in "Design Tips: Using monolithic high voltage gate drivers".

## International **TOR** Rectifier

## **BOARD CONNECTORS**



Figure 1: TOP image of board

#### Connection with the system controller

On board there is a 40 pins connector for the control signals. The driver board uses only 17 pins. The remaining pins are for the sensing board (IRCS2277S) that can be connected on top of IRMD22141SS board.

1 2 10	
10	5 0 6
12	7 () () 8 9 () () 10
13	$11 \bigcirc 0 12 \\ 13 \bigcirc 14 \\ 15 \bigcirc 16$
24	17 () 18 19 () 20
25	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
3	25 O 26 27 O 28 29 O 30
5/6	31 O 32 33 O 34
7 - 40	35 〇 36 37 〇 38 39 〇 40
7 - 20	
	24 25 3 5/6 7 - 40

Input logical signals HIN1, LIN1, HIN2, LIN2, HIN3, LIN3 and FLT\_CLR:

These logic inputs are 3.3 V compatible CMOS I/O port. The logic signals are active high with internal pull-down resistor of 10 kOhm. When both HIN and LIN of the same phase are active at the same time an internal anti-shot trough circuit turns off the output drivers. HIN turns on the high side IGBT while LIN the low side.

International	Datasheet rev 2.1
<b>IC</b> R Rectifier	IRMD22141SS

FLT\_CLR is active high and it is used to reset the fault state of all devices (see also the Fault management section and the IR22141SS datasheet).

#### FAULT/SD logic signal

This is an input/output logic signal, 3.3 V compatible CMOS I/O port. The logic signal is active low, tied to connector VCC with a 10 k $\Omega$  pull-up resistor. As an input, the signal shuts down (SD) all the drivers; as an output, it reports the power module fault (IGBT desaturation detection) or the VCC undervoltage (see also IR22141SS datasheet for more information).

On board a red LED (DL2) indicates when the signal is active; Figure 2a shows the connection.

#### VCC supply pin

This is the supply pin for all the devices. On board a green LED (DL1) indicates the supply power on; Figure 2b shows the connection.



Figure 2: LED connection

#### VSS ground pin (GND)

The board ground is connected to the power module DC- pin. The VSS pin of the connector and the devices ground pin are star-connected to the DC- pin. DC- star connection has been chosen to reduce the noise coupled from the floating signals.

#### Connecting the current sensors

P1, P2 and P3 are connected with the optional shunt resistors placed on the phase output nodes.

CONNECTOR P1				
SHU+ (motor side)	1	1		
SHU- (power module side)	2			
U	3			
C	ONNE	CTOR P2		
SHV+ (motor side)	1	10		
SHV- (power module side)	2	2 0		
V	3			
C	ONNE	CTOR P3		
SHW+ (motor side)	1	1		
SHW- (power module side)	2			
W	3			

Table 2: P1, P2 and P3 connectors for kelvin contacts to shunt signals

International	Datasheet rev 2.1
<b>IOR</b> Rectifier	IRMD22141SS

The SHU, SHV and SHW are sense pins connected as close as possible to the shunt resistors terminals to reduce the parasitic effects of the traces.

#### High power signal connector

There are two connectors dedicated to each power signal (DC+, U, V, W and DC-). Each single connector has 30 Ampere of maximal nominal dc current. DCbus traces are both on top and on one of the internal layers of the PC board in order to reduce power dissipation. Connectors, DC-bus, phase and ground wires can be soldered directly on board using the corresponding pads located under the power connectors (to be removed).

#### Connecting the power module

The board is fully compatible with the ECONO2-6PACK power module. The following table shows the module pin-out.

CONNECTION POINTS BETWEEN BOARD AND MODULE			
1	VGHU - phase U - high side IGBT gate		
2	VEHU - phase U - high side IGBT emitter		
3	VGLU - phase U - low side IGBT gate		
4	VELU - phase U - low side IGBT emitter		
5	VGHV - phase V - high side IGBT gate		
6	VEHV - phase V - high side IGBT emitter		
7	VGLV - phase V - low side IGBT gate		
8	VELV - phase V - low side IGBT emitter		
9	VGHW - phase W - high side IGBT gate		
10	VEHW - phase W - high side IGBT emitter		
11	VGLW - phase W - low side IGBT gate		
12	VELW - phase W - low side IGBT emitter		
13	DC+		
14	Phase W		
15	Phase V		
16	Phase U		
17	DC- (GND)		

Table 3: High power module connection

#### **Test Points**

Test points on board provide signals that are not available at the connectors. See the following table:

ONE FOR EACH DEVICE (U1 -> U, U2 - > V, U3 -> W)			
V <sub>B</sub>	High side floating supply voltage		
Vs	High side floating supply offset voltage		
DSH	High side desat input voltage		
DSL	Low side desat input voltage		
VCC	Low side and logic fixed supply voltage		
GND	Device VSS		
COMMON FOR ALL DEVICES			
FAULT/SD	Fault and Shut Down (or-wired)		
SY_FLT	Synchronized Fault (or-wired)		
Table 4: Test points			

Table 4: Test points

Note: the FAULT/SD signal is present on pin 5 and 6 of the 40-pin connector, too.

## **TEST BENCH CONNECTION**

IRMD22141SS does NOT provide opto isolation.

The following picture shows the recommended connections for board evaluation. Bold lines are equipotential (DC-=Vss=gnd).





## **OPERATING DESCRIPTION**

#### **Power on sequence**

Before beginning the normal operating mode, it is strongly recommended to follow the power ON sequence. The purpose of this procedure is to set the internal device logic. This is achieved by charging all bootstrap capacitors for the first time with the FLT\_CLR signal active. See Figure 4 for the correct procedure.



#### Normal operating mode

In the normal operating mode when HIN or LIN is active the high or low side IGBT turns on respectively. Turn on and turn off propagation delays and the propagation delay matching are specified in the IR22141SS datasheet. Devices introduce also a minimum dead-time (typical 330 ns).

#### Fault management

The IR22141SS is able to detect the excessive current increase by monitoring the IGBT desaturation. The three-phase connection of the IR22141SS allows managing all power module faults using the FAULT/SD and SYNC\_FLT signals in a local network.

Figure 5 shows how the devices are interconnected to each other and with the FAULT/SD pin on the connector. The fault management procedure starts when one of the drivers senses the IGBT desaturation (see Figure 5 where, as an example, only one low side IGBT is shown).

Figure 6 shows an example where the low side IGBT of U1 and U3 and the high side of U2 are on.

The procedure is totally managed by an integrated FAULT LOGIC block without the controller assistance.

# International **ter** Rectifier

## Datasheet rev 2.1 IRMD22141SS



Figure 5: Three phase connection



Figure 6: Example of a desaturation detection event

#### Multilevel board solution

With the optional shunt resistor the IRMD22141SS driver board can be connected with the IRCS2277S current sensing board through J1 and P1, P2, and P3 connectors. More information available with IRCS2277S board datasheet.

## **BOARD SOLUTIONS**

Sizing of the components mentioned in this section is indicated in the Bill of material on page 15.

#### Bootstrap circuit

The high side floating supply (V\_{BS}) is provided by a bootstrap capacitor. Figure 7 shows the circuit on board.



Figure 7: Bootstrap circuit

The following table shows the names of these components on board.

	U	V	W
C <sub>VCC</sub>	C5	C11	C17
C <sub>boot</sub> *	C9	C15	C21
C <sub>boot</sub> **	C8	C14	C20
R <sub>boot</sub> *	R13	R25	R37
R <sub>boot</sub> **	R14	R26	R38

#### Gate resistances

The following table shows the names of gate resistances on board.

	U	V	W
high side gate to HOP	R18	R30	R42
high side gate to HON	R17	R29	R41
high side gate to SSDH	R15	R27	R39
low side gate to LOP	R9	R22	R34
low side gate to LON	R7	R20	R32
low side gate to SSDL	R6	R19	R31

## **OTHER EXTRA COMPONENTS**

These components are provided to make IRMD22141SS board as customizable as possible. In many cases the extra components are not required.

#### Desat circuit

The IR22141S is able to detect the IGBT desaturation. To reject the noise on the desat pins the IR22141SS have an internal filter of 1 $\mu$ sec. If this is not enough an RC filter has been placed on board (see figure 8, R<sub>DSH</sub>, C<sub>DSH</sub> and R<sub>DSL</sub>, C<sub>DSL</sub>).



Figure 8: Desat external filter

The external resistor is in parallel with the internal bias circuit of the desat diode. If added, the external resistor may cause an higher diode bias current that must be taken into account in bootstrap capacitor sizing.

External RC filter delays desaturation detection, that causes a delay in turning the IGBT off. Consider this delay when sizing the soft-shut-down resistors.

The following table shows the names of these components on board.

	U	V	W
C <sub>DSH</sub>	C7	C13	C19
R <sub>DSH</sub>	R16	R28	R40
C <sub>DSL</sub>	C4	C10	C16
R <sub>DSL</sub>	R8	R21	R33

#### **Clamping Diode for Vs below ground**

This solution preserves the device when the  $V_s$  pin goes below ground out of the device absolute maximum ratings. The  $V_s$  voltage is clamped to the maximum value allowed by a zener diode.

# International **ICR** Rectifier



Figure 9: -V<sub>s</sub> clamp

The following table shows the names of these components on board.

	U	V	W
DIODE	D4	D10	D16
ZENER	Z2	Z5	Z8

#### RC filter on com pin

An RC filter ( $R_{COM}$ ,  $C_{COM}$ ) is provided to preserve the IC device from low side IGBT emitter undervoltage spikes.



Figure 10: COM below ground protection

The following table shows the names of these components on board.

	U	V	W
C <sub>COM</sub>	C6	C12	C18
R <sub>COM</sub>	R10	R23	R35

#### Fast diode between gate and supply pin

On all low and high side drivers a fast diode is provided to clamp the gate coming over the  $V_{CC}$  or  $V_B$  supply pins and to recover the current coming from the collector node through the gate-collector capacitance.



Figure 11: Collector-Gate current protection

The following table shows the names of these components on board.

	U	V	W
(high side) $D_G$	D6	D12	D18
(low side) $D_G$	D2	D8	D14

#### Zener diode to preserve the IGBT gate

To avoid a  $V_{GE}$  increasing over the absolute maximum rating a zener diode is connected between gate and emitter pins on all the IGBTs.





The following table shows the names of these components on board.

	U	V	W
(high side) ZENER	Z3	Z6	Z9
(low side) ZENER	Z1	Z4	Z7

#### Optional output shunt resistor

Two type of output shunt resistor, for current sensor, are possible see the following table:

	U	V	W
TO220 or	R3	R4	R5
OARS-1	R3A // R3B	R4A // R4B	R5A // R5B

The OARS-1 type (A and B) are connected in parallel.

#### Resistor on v<sub>cc</sub>

Provided to decouple VCC\_U1, VCC\_U2 and VCC\_U3 from supply line.

	U	V	W
Vcc decoupling	R12	R24	R36

## **BILL OF MATERIAL**

The hereafter provided BOMs represent a suggestion based on the IGBT characteristics shown below.



# International **tor** Rectifier

## Datasheet rev 2.1 IRMD22141SS

## SCHEMATIC



## LAYOUT











